

DE Contents 05 Inhalt 06 Contenu 07 Inhoud 08 Sisältö
 IT Indhold 11 Contenido 12 Contenido 13 Contenido 14 Contenido
 GR Περιεχόμενα SE Innehåll

DE Getting started 05 Erste Schritte 06 Démarrage 07 Aan de slag 08 Aloitussopas 09 Kom i gang
 IT Operazioni preliminari 12 Para empezar 13 Para comenzar 14 Για αρχή 15 Kom igång




x1



x1



x1



x1



x2



x2








x2


CR2032





x1




x1




x1







4x AA/LR6




CR2032








30mm



GB Optional features 05 Optionale Funktionen 06 Options disponibles 07 Opções disponíveis 08 Valinnaiset ominaisuudet 09 Valgtrikje funksjoner 10 Funzionalità opzionali 11 Opciones disponibles
 PT Funções opcionais 02 Προαιρετικές λειτουργίες πρόσθετων 03 Μόβιλις λειτουργίες






| | Hello | Ding Dong | Westminster | Marimba | Piano | Bell | Telephone | Soft Alert |
|--|-------|-----------|-------------|---------|-------|------|-----------|------------|
| | • | • | | | | | • | • |
| | • | • | • | • | | | • | • |
| | • | • | • | • | • | • | • | • |



| | | | | |
|--|--|----------|--|-----------|
| | | 3Hrs | | 6Hrs |
| | | 9Hrs | | 12Hrs |

GB Linking 05 Einlernen 06 Programmation 07 Programação 08 Övöreläring
 NL Verknüpfung 09 Linkittäminen 09 Forbinde
 PT Coligamento 05 Enlace
 PT Programação 06 Övöreläring



GB Trouble shooting 05 Fehlerbehebung 06 Dépannage 07 Probleemoplossing
 FI Vianmääritys 08 Problemlösning 11 Risoluzione dei problemi 03 Solución de problemas
 PT Resolução de problemas 08 Αντιμετώπιση προβλημάτων 09 Felsökning

livewell.honeywell.com

