


DE Contents **DE** Inhalt **FR** Contenu **M** Inhoud **FI** Sisältö
 UK Inhold **IT** Contenuto **ES** Contenido **PT** Conteúdo
GR Περιεχόμενα **SE** Innehåll



x1



x1



x2



x2

CR2032



x1




x1






x2



x1




GR Getting started **DE** Erste Schritte **FR** Démarrage **UK** Aan de slag **FI** Aloitusopas **DK** Kom i gang
IT Operazioni preliminari **ES** Para empezar **PT** Para começar **GR** Πρώτα βήματα **SE** Kom igång




x1



x1



4x C/LR14




30mm






x1



x1




CR2032








15mm




GB Optional features 05 Optionale Funktionen 06 Options disponibles 07 Opções disponíveis
 FI Valinnaiset ominaisuudet 08 Valgfrie funksjoner 09 Funzionalità opzionali 10 Opções disponibles
 PT Funções opcionais 08 Προαιρετικές λειτουργίες πρόσθετων 09 Μόλιγα λειτουργίες



	Hello	Ding Dong	Westminster	Marimba	Piano	Bell	Telephone	Soft Alert
	•	•					•	•
	•	•	•	•			•	•
	•	•	•	•	•	•	•	•



		3Hrs		6Hrs
		9Hrs		12Hrs



GB Trouble shooting 09 Fehlerbehebung 06 Dépannage 07 Probleemoplossing
 FI Vianmääritys 08 Problemløsning 09 Risoluzione dei problemi 10 Solución de problemas
 PT Resolução de problemas 08 Αντιμετώπιση προβλημάτων 09 Felsökníng

livewell.honeywell.com

