

Contents **DE** Inhalt **FR** Contenu **NL** Inhoud **F** Sisältö
DK Indhold **IT** Contenuto **ES** Contenido **PT** Conteúdo
GR Περιεχόμενα **SE** Innehåll



x1



x1



x1



x1



x2




x2



x2



x1



6mm


Getting started **DE** Erste Schritte **FR** Démarrage **NL** Aan de slag **F** Aloitusopas **DK** Kom i gang
IT Operazioni preliminari **ES** Para empezar **PT** Para começar **GR** Πρώτα βήματα **SE** Kom igång





x1




x1






30mm









x1



CR2032







x1




6B Optional features 6B Optionale Funktionen 6B Options disponibles 6B Opciones disponibles
 6B Valimärsed omniausudet 6B Valgfrige funksjoner 6B Funzionalità opzionali 6B Opciones disponibles
 6B Funções opcionais 6B Προαιρετικές λειτουργίες πρόσθετων 6B Mõjiliga funktsionier



	Hello	Ding Dong	Westminster	Marimba	Piano	Bell	Telephone	Soft Alert
64	•	•					•	•
66	•	•	•	•			•	•
68	•	•	•	•	•	•	•	•






6B Trouble shooting 6B Fehlerbehebung 6B Dépannage 6B Probleemoplossing
 6B Vianmääritys 6B Problemløsning 6B Risoluzione dei problemi 6B Solución de
 problemas 6B Resolução de problemas 6B Αντιμετώπιση προβλημάτων 6B Felsökning

livewell.honeywell.com



L430S

- DE Contents
- FR Contenu
- NL Inhoud
- IT Inhoud
- ES Contenido
- PT Conteúdo
- GR Περιεχόμενα
- RU Содержание



x1




x2







x2








x2





- DE Component locations
- FR Montage
- NL Componentlocaties
- IT Asemnusaipen
- ES Ubicaciones de los componentes
- PT Localização dos componentes
- GR Εξοπλισμός
- RU Расположение компонентов





- DE Battery install
- FR Installation des piles
- NL Batterij installeren
- IT Pariston aasmus
- ES Instalación de la batería
- PT Instalação da bateria
- GR Τοποθέτηση της μπαταρίας
- RU Установка ав.батарей




- DE Linking
- FR Liaison
- NL Koppelen
- IT Linkitys
- ES Collegamento
- PT Ligação
- GR Ζεύξη
- RU Слэнканг




- DE Installation
- FR Installation
- NL Installatie
- IT Asemmus
- ES Instalación
- PT Instalação
- GR Τοποθέτηση
- RU Установка




- GB Walk test DE Funktions-test
- FR Test de mise en route NL Loop-test
- FI Kävelytesti MK Gerningangstest
- IT Test intrusione ES Test de paseo
- PT Teste de caminhada GR Δοκιμή βολιμάτων SE Gångtest



- GB Detection area DE Erfassungsbereich
- FR Zone de détection NL Detectiegebied
- FI Tuunnistusalue MK Registeringsområde
- IT Area rilevazione ES Zona de detección
- PT Área de deteção GR Περιοχή ανίχνευσης
- SE Detektionsområde



- GB Operating instructions DE Betriebsmodus FR Instructions opératoires
- NL Bedieningsvoorschriften FI Käyttöohjeet MK Betjeningsvejledning IT Istruzioni operative
- ES Instrucciones de funcionamiento PT Instruções de funcionamento GR Οδηγίες λειτουργίας
- SE Bruksanvisning



- GB Trouble shooting DE Fehlerbehebung FR Dépannage NL Probleemoplossing
- FI Vianmääritys MK Problemløsning IT Risoluzione dei problemi ES Solución de problemas
- PT Resolução de problemas GR Αντιμετώπιση προβλημάτων SE Felsökning

livewell.honeywell.com

